



119-A Hwy 183  
Piedmont, SC 29673  
Tech Support(864) 907-6004 (call or text)  
Email: Tech@DDMWorks.com

## Polaris Slingshot Billet Aluminum Gas Cap DDM-18-5



The Billet aluminum gas cap adds a nice touch to the back of the Slingshot, combining functionality and great looks.

If you are pretty handy with tools the cap can be installed in just a couple minutes, however we suggest that you schedule at least 30 minutes for the installation.

TOOLS NEEDED
5mm allen key
Blade screwdriver

QTY	PART DESCRIPTION
1	DDM-18-5 Biliter gas cap
1	M6 x 12 Socket head bolt
1	M6 oversized stainless flat washer



## DDM-18-5 Billet gas cap

1. First, remove your stock plastic gas cap.
2. Turn the stock cap over and you will see a rubber gasket. Use a flat head screwdriver to carefully pry under the gasket and it will come off the center post that it is mounted with.
3. With the gasket removed from the stock plastic cap, use the supplied washer and bolt to go through the small hole in the center of the factory gasket and secure the gasket to the inside of the new billet gas cap.
4. Install the new cap on your Slingshot and enjoy!


Pry to get under the rubber gasket



Lift the gasket out of the factory gasket



Install gasket to new cap with supplied hardware



This product is  
Buddy the  
Turbo Dog  
Approved!



119-A Hwy 183

Piedmont, SC 29673

**Tech Support**