



## SLINGSHOT UPHOLSTERED AND PADDED ARM REST DDM-17-1



QTY	PART DESCRIPTION
1	Driver side upholstered arm rest
1	Passenger side upholstered arm rest
2	Alcohol Prep pads
1	Adhesion promoter packet

### IMPORTANT—PREP PROPERLY BEFORE INSTALLATION!!!

Before installation, it is extremely important that the areas are prepped properly. If you have used any shining or waxing agents on this area you will need to use a cleaner to remove any product or residue.

Next clean the area using the alcohol prep pads provided. Then cover the area with the adhesion promoter.

You can now apply your comfy new arm rests!

If you have any questions during the installation you can call or text (864) 907-6004 or email us at [Tech@ddmworks.com](mailto:Tech@ddmworks.com).



(864) 907-6004 (call or text)  
Email: [Tech@DDMWorks.com](mailto:Tech@DDMWorks.com)



This product is  
Jake the  
Supercharger  
Dog

