

Nelson & Nelson Mfg.

5210 Stadium Blvd, Suite C Jonesboro AR 72404 870-268-6393 : Cell 219-1019

Installation Instructions 3-16-23

Model SF3RT-USB-2

12 VOLT ADD-ON FLAT PLATE DUAL USB SOCKET. MOUNTS ON RAM MOUNT ARMS.

Steps needed to install your 12-volt unit.

1.- This unit installs over the ¼" bolt that is located on the twist knob of a ram mount arm product.

2.- remove twist knob and place 12-volt unit over the bolt of the ram mount or run the bolt of the knob through the mount hole. Place the 12-volt socket at ant position that works best with the ram mount arm assuring easy access to the dual USB sockets.

3.-Run power wires to a fused power location on your Spyder.



The Mount Arm above is NOT included shown for install only.

We thank you for purchasing of our 12-volt power stations products. Today we know the needs for 12-volt power for accessories and we have solved that demand with a stylish system that compliments the design of your Spyder!